

BREEK ARMS PLAN-B HUB ONE TITANIUM SUPPRESSOR MOUNT

BEFORE PERFORMING ANY MAINTENANCE, REVIEW YOUR FIREARM'S SAFETY MANUAL THOROUGHLY. IF YOU'RE UNSURE OR UNCOMFORTABLE WITH ANY PART OF THE PROCESS, CONSULT A QUALIFIED GUNSMITH FOR ASSISTANCE.

ATTACHING THE PLAN-B MOUNT TO YOUR SUPPRESSOR

1. BEGIN BY FOLLOWING THE INSTRUCTIONS IN YOUR SUPPRESSOR'S MANUAL TO REMOVE THE EXISTING MOUNT.
2. CAREFULLY THREAD THE PLAN-B MOUNT INTO THE SUPPRESSOR BY HAND. BE SURE IT STARTS CLEANLY TO AVOID CROSS-THREADING.
3. USING A $1\frac{1}{4}''$ WRENCH OR YOUR BREEK PLAN-B WRENCH, TORQUE THE PLAN-B MOUNT TO APPROXIMATELY 35 FT-LBS [CHECK YOUR SILENCER'S MANUAL FOR SPECIFIC GUIDELINES].



BREEK ARMS PLAN-B MUZZLE DEVICES AVAILABLE AT BREEKARMS.COM

